




PARTS MANUAL EDGING POWER TROWEL MT24 / MT30






MT24 / MT30 PARTS LIST 1

MT24 / MT30 PARTS LIST 1

ITEM NO.	PART NO.	DESCRIPTION	QTY
1	M300100001	SCREW	2
2	M300100002	PLATE	1
3	M300100003	WASHER	1
4	M300100004	SCREW NUT	1
5	M300100005	SCREW	1
6	M300100006	NUT	2
7	M300100007	WASHER	1
8	M300100008	SCREW	2
9	M300100009	SCREW	1
10	M300100010	THROTTLE CONTROL	1
11	M300100011	SAFETY STOP SWITCH ASSY.	1
12	M300100012	SHAFT, TROWEL CONTROL	1
13	M300100013	COLLAR	1
14	M300100014	BOLT	1
15	M300100015	PIN	1
16	M300100016	WHEEL, HAND HANDLE	1
17	M300100017	HANDLE	1
18	M300100018	GRIP	2
19	M300100019	WIRE	1
20	M300100020	TIE WIRE	1
21	M300100021	CLIP	1
22	M300100022	NUT	2
23	M300100023	SPACER	1
24	M300100024	SPRING WASHER	1
25	M300100025	BERING	1
26	M300100026	PIN	1
27	M300100027	SCREW	1
28	M300100028	BRACKET, HANDLE ADJUSTABLE	1
29	M300100029	SCREW	1
30	M300100030	NUT	1
31	M300100031	HANDLE ADJUSTABLE	1



MT24 / MT30 PARTS LIST 2


MT24 / MT30 PARTS LIST 2

ITEM NO.	PART NO.	DESCRIPTION	QTY
32	M300200001	SCREW MIZ	1
33	M300200002	THRUST COLLAR	1
34	M300300000-1	SPIDER PLATE ASSY. FOR MT30	1
	M300300000-2	SPIDER PLATE ASSY. FOR MT24	1
35	M300200003	PIN	1
36	M300200004	WEAR PLATE FOR MT30	1
	M300200004-1	WEAR PLATE FOR MT24	1
37	M300200005	BEARING	1
38	M300200006	WEAR RING	1
39	M300200007	ARM, YOKE	1
40	MTBF06105	BLADE FOR MT30	4
	MTBC04009	BLADE FOR MT24	4
41	M300300001	TROWEL ARM EXTENDED FOR MT30	4
	M300300001-1	TROWEL ARM EXTENDED FOR MT24	4
42	M300300002	SPACER FOR MT30	8
	M300300002-1	SPACER FOR MT24	8
43	M300300003	SPRING WASHER FOR MT30	8
	M300300003-1	SPRING WASHER FOR MT24	8
44	M300300004	SCREW FOR MT30	8
	M300300004-1	SCREW FOR MT24	8
45	M300300005	TROWEL ARM LEVER FOR MT30	4
	M300300005-1	TROWEL ARM LEVER FOR MT24	4
47	M300300007	ROLL PIN FOR MT30	4
	M300300007-1	ROLL PIN FOR MT24	4
48	M300300008	RADIUS HEAD SCREW FOR MT30	4
	M300300008-1	RADIUS HEAD SCREW FOR MT24	4
49	M300300009	NUT FOR MT30	8
	M300300009-1	NUT FOR MT24	8
50	M300300010	SPIDER PLATE ONLY FOR MT30	1
	M300300010-1	SPIDER PLATE ONLY FOR MT24	1
51	M300200008	BEARING	4
52	M300200009	BEARING	4

(TO BE CONTINUED)

MT24 / MT30 PARTS LIST 2

ITEM NO.	PART NO.	DESCRIPTION	QTY
53	M300400001	RUBBER RING FOR MT30	4
	M300400001-1	RUBBER RING FOR MT24	4
54	M300200010	PIN, YOKE	1
55	M300200011	WASHER	2
56	M300500001	SPACER	2
57	M300500002	SCREW M8	2
58	M300500003	SCREW M6	4
59	M300500004	SPACER	4
60	M300500005	BELT GUARD	1
61	M300500006	FRONT ENGINE MOUNTING PLATE	1
62	M300500007	BELT COVER - INSIDE	1
63	M300500008	PULLEY	1
64	M300500009	KEY	1
65	M300500010	SCREW, FLAT HEAD	4
66	M300500011	NUT	4
67	M300500012	RUBBER WASHER	4
68	M300500013	BOLT	1
69	M300400002	RING GUARD FOR MT30	1
	M300400002-1	RING GUARD FOR MT24	1
70	M300500014	SCREW M8X45	4
71	M300600000	GEARBOX ASSY.	1
72	M300500015	SPACER	4
73	M300500016	SPRING WASHER	4
74	M300500017	NUT	4
75	M300500018	BELT	1
76	M300500019	SCREW	1
77	M300500020	SPRING WASHER	1
78	M300500021	SPACER	1
79	M300700000	CLUTCH ASSY.	1
80	M300500022	KEY	1
81	M300500023	WASHER	1
82	M300500024-1	PETROL ENGINE, ROBIN EX13 FOR MT24	1
	M300500024-2	PETROL ENGINE, ROBIN EX17 FOR MT30	1
	M300500024-3	PETROL ENGINE, HONDA GX160	1




MT24 / MT30 PARTS LIST 3

MT24 / MT30 PARTS LIST 3

ITEM NO.	PART NO.	DESCRIPTION	QTY
83	M300600001	SCREW M8	8
84	M300600002	SCREW	1
85	M300600003	COVER, GEAR BOX	1
86	M300600004	SEAL	1
87	M300600005	SCREW M10	1
88	M300600006	SPACER	1
89	M300600007	SEAL	1
90	M300600008	SCREW	4
91	M300600009	FLANGE, INPUT SHAFT	1
92	M300600010	PLATE, SEAL	1
93	M300600011	O-RING	1
94	M300600012	BEARING	1
95	M300600013	GEAR, WORM & SHAFT ASSY.	1
96	M300600014	BEARING	1
97	M300600015	SEAL, OIL	1
98	M300600016	CASE, GEAR	1
99	M300600017	SEAL	1
100	M300600018	SIGHT GLASS	1
101	M300600019	FITTING, PLUG	2
102	M300600020	FLANGE	1
103	M300600021	SCREW M6	4
104	M300600022	SEAL	1
105	M300600023	O-RING	1
106	M300600024	KEY	1
107	M300600025	SHAFT	1
108	M300600026	BEARING	1
109	M300600027	GEAR, WORM	1
110	M300600028	BEARING	1



Distributed By



MASALTA ENGINEERING CO., LTD

Add: Weisi Road, Baohe Industrial Estate, Hefei, China
Tel: 86-551-4846600, 4846601 Fax: 86-551-4846616
E-mail: sales@masalta.com.cn, masalta@mail.hf.ah.cn,
[Http://www.masalta.com.cn](http://www.masalta.com.cn)